

# Assembly



IMPORTANT! Please read entire instructions before assembly.

Each box contains:

- \* (4) 48" x 48" x 2" Modules
- \* (8) Black EZ Pad connectors
- \* (16) Phillips Pan head size 14, 1-inch screws

Tools Needed for Installation:

Shovel, Level, 2x4 to assist in leveling dirt, sand or gravel, Phillips head screwdriver or cordless drill.

Instructions:

The EZ Pad modules can be placed on grass, dirt, sand or gravel. For best results, prepare a level sand base. Module can be drilled through for electrical conduit placement.

1. Line up modules bottom side up in desired configuration, i.e., 4 modules make an 8' x 8' square.



Exhibit A

4. Remove the black connectors from their storage pockets.



Exhibit D

2. Locate the adjoining pockets on each module and insert connectors into adjoining pockets. Apply downward pressure to lock them in place.



Exhibit B

5. Locate bag of screws. Use two screws for each connector. You will find one screw hole on each end of the connector. Be careful not to sink the screw too far, just enough to firmly hold down the connector. Repeat procedure until all 8 connectors are installed.



Exhibit E

3. Turn the Pad over with the help of at least 2 more individuals. Place one person on each of 3 sides. Lift together standing it on end and slowly flip it over



Exhibit C

6. Place on prepared surface. Do not be alarmed if it flexes when carried



Exhibit F

## Conduit installation instructions

Using a 1" hole saw, drill from the bottom of the EZ Pad in the center of one of the recesses to simplify conduit insertion.

